

BMW Motorrad

Maintenance schedule

0186 - F 650 GS Dakar



00 00 125 BMW Service with Annual Inspection (see Maintenance Schedule) (annually, initially at 10,000 km, then every 20,000 km)

_____	_____	_____
Customer	Registration No.	Odometer reading
_____	_____	_____
Order No.	Date	Mechanic's + Manager's signature

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Changing engine oil (engine and oil tank) and oil filter element	<input type="checkbox"/>
Checking coolant level	<input type="checkbox"/>
17 00 505 Change coolant in system (maintenance) *)	<input checked="" type="checkbox"/> every four years
Checking valve clearance	<input type="checkbox"/>
Replacing spark plugs	<input checked="" type="checkbox"/> initially at 30,000 km, then every 20,000 km
Emptying drain hose from intake air silencer	<input type="checkbox"/>
Checking clutch play	<input type="checkbox"/>
Checking spoke tension, adjusting if necessary	<input type="checkbox"/>
Checking battery acid level	<input type="checkbox"/>
Cleaning and greasing battery terminals	<input type="checkbox"/>
Checking front brake fluid level	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake disc for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake disc for wear	<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes *)	<input checked="" type="checkbox"/> every two years
Changing brake fluid, rear brakes	<input type="checkbox"/>
Checking chain, chain sprocket and chain pinion	<input type="checkbox"/>
Checking chain takeup roller and slider rail	<input type="checkbox"/>
Checking chain tension	<input type="checkbox"/>

Checking steering head bearing play	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>
Lubricating side stand	<input type="checkbox"/>
Lubricating footbrake lever	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: engine / main frame, engine / engine carrier and cylinder head / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: main frame / rear frame, frame bottom section / main frame and engine carrier / main frame	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: footrest plate / main frame and side stand / bottom truss	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: spring strut / angled lever / frame / reaction link	<input type="checkbox"/>
Checking specified torque of threaded fasteners with torque wrench: exhaust system	<input type="checkbox"/>
Checking tyre pressures and tread depth	<input type="checkbox"/>
Checking lights and signalling equipment	<input type="checkbox"/>
Final inspection and function check	<input type="checkbox"/>
Confirming BMW Service in on-board documentation	<input type="checkbox"/>

*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4
06.06.06

BMW recommends 