

BMW Motorrad

Maintenance schedule

0389 - HP2 Enduro



00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

Customer

Registration No.

Odometer reading

Order No.

Date

Mechanic's + Manager's signature

Reading fault memory with (BMW Motorrad) diagnostic system		<input type="checkbox"/>
Engine-oil change, with filter		<input type="checkbox"/>
23 00 510 Gearbox-oil change (maintenance *)	every two years or every 40,000 km	<input type="checkbox"/>
Adjusting valve clearance		<input type="checkbox"/>
12 12 509 Replace all spark plugs (as part of maintenance *)	every 40,000 km	<input type="checkbox"/>
Replacing air filter element		<input type="checkbox"/>
Visual inspection of hydraulic clutch system		<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections		<input type="checkbox"/>
Checking front brake disc for wear		<input type="checkbox"/>
Checking front brake pads for wear		<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes *)	every two years	<input type="checkbox"/>
Checking brake-fluid level, front brakes		<input type="checkbox"/>
Checking rear brake disc for wear		<input type="checkbox"/>
Checking rear brake pads for wear		<input type="checkbox"/>
Changing brake fluid, rear, and bleeding brake system		<input type="checkbox"/>
Checking steering-head bearing		<input type="checkbox"/>
31 42 843 Cleaning, checking and bleeding fork legs (for maintenance *)	for sporty off-roading	<input type="checkbox"/>
31 42 902 Changing fluid in telescopic forks (for maintenance *)	for sporty off-roading	<input type="checkbox"/>
46 51 801 Checking security of threaded fasteners *)	for sporty off-roading	<input type="checkbox"/>
12 31 657 Repleace belt for generator (as part of maintenance *)	every 60,000 km	<input type="checkbox"/>
12 31 646 Checking belt for alternator (for maintenance *)	for sporty off-roading	<input type="checkbox"/>
46 51 800 Checking pivots of running gear, foot- operated lever and		<input type="checkbox"/>

side stand *)

for sporty off-riding 

Checking freedom of movement of throttle cable and checking for kinks and chafing

Checking spoke tension, adjusting if necessary

Checking tyre pressures and tread depth

Checking ease of movement of side stand

Checking lights and signalling equipment

Function test, engine start suppression

Checking synchronisation

Test ride as final inspection and function check

Reading fault memory with (BMW Motorrad) diagnostic system

Checking battery charge state

Confirming BMW Service in on-board documentation

*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4
06.06.06

BMW recommends 