

# BMW Motorrad

## Maintenance schedule



### 0492 - R 1150 GS Adventure

00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

_____	_____	_____	<b>Equipment trim-level variant:</b> 0684 - ABS II
Customer	Registration No.	Odometer reading	
_____	_____	_____	
Order No.	Date	Mechanic's + Manager's signature	

Reading fault-code memories with the BMW Motorrad diagnostic system	<input type="checkbox"/>
Changing engine oil with engine at operating temperature, replacing oil filter	<input type="checkbox"/>
Changing oil in gearbox, warmed to normal operating temperature	<input type="checkbox"/>
33 00 501 Oil change, rear wheel drive *)	every two years or every 40,000 km <input type="checkbox"/>
16 12 525 Replace the fuel filter (during maintenance) *)	every 40,000 km <input type="checkbox"/>
Checking battery acid level	<input type="checkbox"/>
Cleaning and greasing battery terminals	<input type="checkbox"/>
Replacing intake air filter	<input type="checkbox"/>
Checking front brake fluid level	<input type="checkbox"/>
Checking brake-fluid level, rear brake	<input type="checkbox"/>
Visual inspection of the brake pipes, brake hoses and connections	<input type="checkbox"/>
Checking front brake pads for wear	<input type="checkbox"/>
Checking front brake discs for wear	<input type="checkbox"/>
Checking rear brake pads for wear	<input type="checkbox"/>
Checking rear brake disc for wear	<input type="checkbox"/>
34 00 548 Changing brake fluid, front brakes *)	every two years <input type="checkbox"/>
34 00 549 Changing brake fluid, rear brakes *)	every two years <input type="checkbox"/>
Checking clutch fluid level	<input type="checkbox"/>
21 00 505 Change the clutch fluid (during maintenance) *)	every four years <input type="checkbox"/>
Checking rear wheel bearing play by tilting wheel	<input type="checkbox"/>
Checking swinging-arm pivot mount	<input type="checkbox"/>
Checking operation of side-stand switch	<input type="checkbox"/>
Greasing side stand pivot	<input type="checkbox"/>

12 31 657 Repleace belt for generator (as part of maintenance \*)

every 40,000 km

Replacing spark plugs

Adjusting valve clearance

Checking freedom of movement of throttle cable and checking for kinks and chafing

Checking/adjusting synchronisation

Checking tyre pressures and tread depth

Checking spoke tension

Checking lights and signalling equipment

Test ride as final inspection and function check

Confirming BMW Service in on-board documentation

\*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4  
18.05.06

BMW recommends

